



ASSEMBLY INSTRUCTION

NP2XL | 1/4" Professional Phone Plug

- A** Slide the boot onto the cable.
- B** Prepare cable as shown.
Suitable cable O. D. 8 - 10 mm [0.31 - 0.39"]
- C** Solder the wire ends.
- D** Position the spacer ring (1.) and the chuck (2.) onto the cable and align chuck with plugfinger.
Attention: Pay attention to the guiding key.
- E** Slide the housing onto the plugfinger with the chuck.
- F** Finish the installation by tighten the bushing onto the connector.
-

NEUTRIK AG LI T: +423 / 237 24 24 F: +423 / 232 53 93
NEUTRIK USA Inc. USA T: +1 732 / 901 9488 F: +1 732 / 901 9608
NEUTRIK (UK) Ltd. UK T: +44 1983 / 811 441 F: +44 1983 / 811 439
NEUTRIK Vertriebs GmbH DE/NL/AT/DK T: +49 8131 / 280 890 F: +49 8131 / 280 830

NEUTRIK France FR T: +33 1 / 4131 6750 F: +33 1 / 4131 0511
NEUTRIK Tokyo Ltd. JP T: +81 3 / 3663 4733 F: +81 3 / 3663 4796
NEUTRIK Hong Kong Ltd. HK T: +852 / 2687 6055 F: +852 / 2687 6052

Draft. Nr.: BDA 204 / 3102M1611 | Update: 14.06.2010 | Data subject to change without prior notice. ©2010 NEUTRIK®. ALL RIGHTS RESERVED.

www.neutrik.com

NEUTRIK